

Code Lists / Liste des codes / Lista de Códigos

Audio

Amplifier / Amplificateur / Amplificador

Durabrand.....	1561
Harman/Kardon.....	0892
JVC.....	0331
Left Coast.....	0892
Lennox.....	1561
Marantz.....	0892
Optimus.....	1189
Philips.....	0892
Pioneer.....	1390
Polk Audio.....	0892
RCA.....	0823
Sony.....	0815
Victor.....	0331
Yamaha.....	0354

Receiver / Récepteur / Receptor

Accurian.....	2098
Aiwa.....	1405, 0189, 0121, 1243, 1641
Akai.....	1512
Alco.....	1390
Anam.....	1609, 1074
Apex Digital.....	1257, 1430, 1774
AudioTronic.....	1189
Audiovox.....	1390
B & K.....	0701, 0820, 0840
Bose.....	1229, 0639, 1253, 1629, 1841, 1933
Cambridge Soundworks.....	1370, 2297
Carver.....	1189, 0189
Daewoo.....	1250
Denon.....	1360, 1142, 2279, 2857
Fisher.....	1801
Gateway.....	1517
Go Video.....	1532
Harman/Kardon.....	0189, 0891, 1304, 1306, 2241
Hitachi.....	1801
Insignia.....	1030, 1077, 1893, 2169, 2175
Integra.....	0135, 1298, 1320, 1805
JVC.....	1374, 1676, 1871, 2239, 2331
Kenwood.....	1313, 1570, 1569, 0186
KLH.....	1390, 1412, 1428
Koss.....	1366
LG.....	0476
Linn.....	0189
Magnavox.....	1189, 1269, 0189, 0391, 1514
Marantz.....	1189, 1269, 0189, 1289
Mitsubishi.....	1393
Onkyo.....	0135, 0842, 1298, 1320, 1531, 1805
Optimus.....	1023, 0186, 1074
Oritron.....	1366
Panasonic.....	1308, 0367, 1288, 1316, 1548, 1633, 1763, 1764, 2967
Philips.....	1189, 1269, 0189, 0391, 1266, 1831, 2311
Pioneer.....	1023, 0244, 0630, 1123, 1384, 1935
Polaroid.....	1508
Polk Audio.....	0189, 1289
Proscan.....	1254
RCA.....	1023, 1609, 1254, 1074, 1123, 1390, 1511, 2041
Rio.....	1869

Audio Accessories / Accessoires de audio / Accesorios de audio

Accurian.....	1106
Altec Lansing.....	0607
Apple.....	1115, 1644
D-Link.....	1522
DLO.....	1155
GPX.....	2113
Griffin.....	1891
iDeck.....	1106
iLive.....	2113
Monitor Audio.....	1106
NaviPod.....	1644
Netgear.....	1785
Roku.....	1828
SSI.....	1522
Yamaha.....	1809, 1810

Cable / Câble

Amino.....	1602, 1822
Bright House.....	1376, 1877
Cable One.....	1376, 1877
Cablevision.....	1376, 1877
Charter.....	1376, 1877, 2187
Cisco.....	1877, 0877, 1982
Comcast.....	1376, 1877, 1982, 2576
Cox.....	1376, 1877
Digeo.....	1187, 2187
Director.....	0476
General Instrument.....	0476
Homecast.....	2301
i3 Micro.....	1602
Insight.....	1376, 1877
Jerrold.....	1376, 1877
Mediacom.....	1376, 1877
Motorola.....	1376, 1877, 1187
Myrio.....	1376, 0476, 1187
Pace.....	1877
Panasonic.....	1877
Pioneer.....	1877, 0877
Scientific Atlanta.....	1877, 0877
Sejin.....	1602
Suddenlink.....	1376, 1877
Time Warner.....	1376, 1877, 2187
Tivo.....	2576

Cable-DVR Combos / Combinés Câble - DVR / Combos de Cable-DVR

Amino.....	1822
Bright House.....	1376, 1877
Cable One.....	1376, 1877
Cablevision.....	1376, 1877
Charter.....	1376, 1877, 2187
Cisco.....	1376, 1877, 1982, 2576
Comcast.....	1376, 1877, 1982, 2576
Cox.....	1376, 1877
Digeo.....	1187, 2187
Homecast.....	2301
Insight.....	1376, 1877
Mediacom.....	1376, 1877
Motorola.....	1376, 1877, 1187
Myrio.....	1376, 0476, 1187
Pace.....	1877
Panasonic.....	1877
Pioneer.....	1877, 0877
Scientific Atlanta.....	1877, 0877
Sejin.....	1602
Suddenlink.....	1376, 1877
Time Warner.....	1376, 1877, 2187
Tivo.....	2576

Bell ExpressVu.....	0775, 1170
Chaparral.....	0216
Coolsat.....	1806
Voom.....	0869
Dish Network.....	1109
DirecTV.....	1377, 0392, 0566, 0639, 1639, 1142, 0247, 0749, 1749, 1856, 1076, 1109, 1189, 1414, 1442, 1443, 1609, 1708
Dish Network System.....	0775, 1505, 1170, 1775
Dishpro.....	0775, 1505, 1775
EChostar.....	0775, 1505, 1170, 1775
Expressvu.....	0775, 1775
GE.....	0775, 1505
General Instrument.....	0869
GOI.....	0775, 1775
Hitachi.....	1250
HTS.....	0775, 1775
Hughes Network Systems.....	1142, 0749, 1749, 1442, 1443
Humax.....	1790
JVC.....	0775, 1170, 1775
LG.....	1414
Mitsubishi.....	0749
Motorola.....	0869
Next Level.....	0869
Panasonic.....	0247, 0701, 1189
Pansat.....	1807
Philips.....	1142, 0749, 1749, 1076, 1442
Proscan.....	0392, 0566
RadioShack.....	0869
RCA.....	0566, 0143
Samsung.....	1377, 1276, 1109, 1442, 1609, 1708
Sony.....	0639, 1639
Star Choice.....	0869
Tivo.....	1142, 1442, 1443

Satellite / Satélite

Bell ExpressVu.....	0775, 1170
DirecTV.....	1377, 0392, 0639, 1142, 1076, 1442, 1443
Dish Network System.....	0775, 1505
Dishpro.....	0775, 1505
EChostar.....	0775, 1505, 1170, 1775
Expressvu.....	0775, 1505
GE.....	0775, 1505
General Instrument.....	0869
GOI.....	0775, 1775
Hitachi.....	1250
HTS.....	0775, 1775
Hughes Network Systems.....	1142, 0749, 1749, 1442, 1443
Humax.....	1790
JVC.....	0775, 1170, 1775
LG.....	1414
Mitsubishi.....	0749
Motorola.....	0869
Next Level.....	0869
Panasonic.....	0247, 0701, 1189
Pansat.....	1807
Philips.....	1142, 0749, 1749, 1076, 1442
Proscan.....	0392, 0566
RadioShack.....	0869
RCA.....	0566, 0143
Samsung.....	1377, 1276, 1109, 1442, 1609, 1708
Sony.....	0639, 1639
Star Choice.....	0869
Tivo.....	1142, 1442, 1443

Toshiba.....	0749, 1749, 0790
Ultrasat.....	1806
Voom.....	0869
Zenith.....	1856

Satellite-DVR Combos / Combinés Satellite - DVR / Combos de Satélite-DVR

Bell ExpressVu.....	0775, 1170
DirecTV.....	1377, 0392, 0639, 1142, 1076, 1442, 1443
Dish Network System.....	0775, 1505
Dishpro.....	0775, 1505
EChostar.....	0775, 1505, 1170, 1775
Expressvu.....	0775, 1505
GE.....	0775, 1505
General Instrument.....	0869
GOI.....	0775, 1775
Hitachi.....	1250
HTS.....	0775, 1775
Hughes Network Systems.....	1142, 0749, 1749, 1442, 1443
Humax.....	1790
JVC.....	0775, 1170, 1775
LG.....	1414
Mitsubishi.....	0749
Motorola.....	0869
Next Level.....	0869
Panasonic.....	0247, 0701, 1189
Pansat.....	1807
Philips.....	1142, 0749, 1749, 1076, 1442
Proscan.....	0392, 0566
RadioShack.....	0869
RCA.....	0566, 0143
Samsung.....	1377, 1276, 1109, 1442, 1609, 1708
Sony.....	0639, 1639
Star Choice.....	0869
Tivo.....	1142, 1442, 1443

GoldStar.....	0741
GPX.....	0699, 0769
Greenhill.....	0717
Harman/Kardon.....	0582, 0702, 1229
Helios.....	2192
Hello Kitty.....	0831
Hitachi.....	0573, 0664, 1247, 1919
Hiteker.....	0672
Humax.....	1588
iLO.....	1348, 1472
Initial.....	0717, 1472
Insignia.....	0675, 1268, 2095, 2428
Integra.....	0627, 1769, 2147
JBL.....	0702
Jensen.....	1016
JSI.....	1423
AMW.....	0872, 1245
Apex Digital.....	0672, 0717, 0755, 0794, 0796, 0797, 0830, 1004, 1056, 1061, 1100, 1480
Kawasaki.....	0790
Kenwood.....	0490, 0534, 0682
KLH.....	0717, 0790, 1149, 1261
Konka.....	0711, 0719, 0270
Koss.....	0651, 0896, 1423
Lasonic.....	0798, 1173
Lennox.....	1127
LG.....	0591, 0741, 0869, 1526
LiteOn.....	1058, 1158, 1416, 1440, 1656, 1738
Loewe.....	0511
Magnavox.....	0503, 0539, 0646, 0675, 0821, 1268, 1354, 1472, 1506
Malata.....	0782
Marantz.....	0539, 2414
McIntosh.....	1273
Memorex.....	0695, 0831, 1270, 2213
Microsoft.....	0522, 2083
Mintek.....	0839, 0717, 1472
Myrio.....	0839
Citizen.....	0790
Coby.....	0778, 0852, 1086, 1107, 1165, 1177, 1351
NAD.....	0831
Curtis Mathes.....	1087
CyberHome.....	0816, 0874, 1023, 1024, 1117, 1129, 1502, 1537
NEC.....	0785
Nesa.....	0717
NexxTech.....	1402
Norcent.....	1003, 0872, 1107, 1265, 1457
Olevia.....	2331

DVD / Lecteurs DVD

Accurian.....	0675, 1416
Advent.....	1016
Aiwa.....	0641
Akai.....	0695, 0770, 0899, 1089
Alco.....	0790
Allegro.....	0869
Amphion Media Works.....	0872, 1245
AMW.....	0872, 1245
Apex Digital.....	0672, 0717, 0755, 0794, 0796, 0797, 0830, 1004, 1056, 1061, 1100, 1480
Arrgo.....	1023
Aspire Digital.....	1168, 1407
Astar.....	1489, 1678
Audiovox.....	0790, 1121, 1122
B & K.....	1628
BBK.....	1224
Bel Canto Design.....	1571
Blaupunkt.....	0717
Blue Parade.....	0571
Bose.....	2023
Broksonic.....	0695, 0868, 1419
Buffalo.....	1882
Centrios.....	1577
CineVision.....	0876, 0833, 0869
Citizen.....	0695, 1277
Coby.....	0778, 0852, 1086, 1107, 1165, 1177, 1351
NAD.....	0831
Curtis Mathes.....	1087
CyberHome.....	0816, 0874, 1023, 1024, 1117, 1129, 1502, 1537
D-Link.....	1881
D-Vision.....	1173

Daewoo.....	0784, 0705, 0833, 0869, 1169, 1172, 1234, 1242, 1441, 1443
Denon.....	0490, 0634, 2258
Desay.....	1407
Diamond Vision.....	1316, 1609, 1610
DigitalMax.....	1738
Disney.....	0675, 1270
Dual.....	1068, 1085
Durabrand.....	1127, 2164
DVD2000.....	1738
Emerson.....	0591, 0675, 0821, 1268
Enterprise.....	0591
ESA.....	0821, 1268, 1443
Presidian.....	0670, 1919
Fisher.....	0675, 1268, 1334
Funai.....	1963
Gateway.....	1073, 1077, 1158
GE.....	0522, 0815, 0717
GFM.....	0675, 1268
Go Video.....	0744, 0715, 0741, 0783, 0833, 0869, 1044, 1075, 1099, 1144, 1158, 1304, 1443, 1730
GoldStar.....	0741
GPX.....	0699, 0769
Greenhill.....	0717
Harman/Kardon.....	0582, 0702, 1229
Helios.....	2192
Hello Kitty.....	0831
Hitachi.....	0573, 0664, 1247, 1919
Hiteker.....	0672
Humax.....	1588
iLO.....	1348, 1472
Initial.....	0717, 1472
Insignia.....	0675, 1268, 2095, 2428
Integra.....	0627, 1769, 2147
JBL.....	0702
Jensen.....	1016
JSI.....	1423
AMW.....	0872, 1245
Apex Digital.....	0672, 0717, 0755, 0794, 0796, 0797, 0830, 1004, 1056, 1061, 1100, 1480
Kawasaki.....	0790
Kenwood.....	0490, 0534, 0682
KLH.....	0717, 0790, 1149, 1261
Konka.....	0711, 0719, 0270
Koss.....	0651, 0896, 1423
Lasonic.....	0798, 1173
Lennox.....	1127
LG.....	0591, 0741, 0869, 1526
LiteOn.....	1058, 1158, 1416, 1440, 1656, 1738
Loewe.....	0511
Magnavox.....	0503, 0539, 0646, 0675, 0821, 1268, 1354, 1472, 1506
Malata.....	0782
Marantz.....	0539, 2414
McIntosh.....	1273
Memorex.....	0695, 0831, 1270, 2213
Microsoft.....	0522, 2083
Mintek.....	0839, 0717, 1472
Myrio.....	0839
Citizen.....	0790
Coby.....	0778, 0852, 1086, 1107, 1165, 1177, 1351
NAD.....	0831
Curtis Mathes.....	1087
CyberHome.....	0816, 0874, 1023, 1024, 1117, 1129, 1502, 1537
NEC.....	0785
Nesa.....	0717
NexxTech.....	1402
Norcent.....	1003, 0872, 1107, 1265, 1457
Zoec.....	1265

Onkyo.....	0503, 0627, 1769, 2120, 2147
Oppo.....	0575, 1224, 2185
OptoMedia Electronics.....	0896
Oritron.....	0651
Panasonic.....	0490, 0632, 0703, 1362, 1462, 1490, 1641, 1762
Philco.....	0675
Philips.....	0503, 0539, 2056, 0646, 0675, 0854, 1260, 1267, 1340, 1354, 2084, 2334, 2434
Pioneer.....	0525, 0571, 0142, 0631, 0632, 1460, 1571, 2442
Polaroid.....	1061, 1086, 1245, 1261, 1316, 1478, 1480, 1482, 2313
Polk Audio.....	0539
Portland.....	0770
Presidian.....	0675, 1738
Prima.....	1016
Funai.....	1348
GFM.....	1963
LG.....	1164, 1275
LiteOn.....	1158, 1416, 1440, 1738
Magnavox.....	0646, 0675, 1506
Panasonic.....	

TV/VCR Combos / Combinés téléviseur -magnétoscope / Combos de TV-VCR

Table listing TV/VCR combinations with brands like American Action, Audiovox, Dell, DirecTV, Dish Network System, and others.

DTV Converters / Récepteurs TV numériques / Convertisseurs Digitales

Table listing DTV converters with brands like Access HD, Airlink 101, Alpha Digital, AMTC, and others.

DVRS

Table listing DVRs with brands like ABS, Alienware, Bell ExpressVu, CyberPower, and others.

Video Accessories / Accessoires de vidéo / Accesorios de vídeo

Table listing video accessories with brands like ABS, Access HD, ADB, Verizon, and others.

TVs / Téléviseurs

Table listing TVs with brands like Accurian, Action, Admiral, and others.

Table listing TVs with brands like Daewoo, Dell, Denon, Diamond Vision, and others.

Table listing TVs with brands like LXI, MAG, Magnavox, Marantz, Matsushita, and others.

Table listing TVs with brands like Runco, Sampo, Samsung, Sansui, Sanyo, and others.

Table listing TVs with brands like DLP, Hewlett Packard, HP, Magnavox, Mitsubishi, and others.

Table listing TVs with brands like LCD / ACL, Accurian, Action, Akai, and others.

Table listing TVs with brands like Insignia, Akai, Albatron, AOC, and others.

Plasma Akai 0812, 1675, 1207, 2078 Albatron 0843 AOC 1590 Aomni 1623 BenQ 1032 Byd:sign 1311 Daewoo 0661 Dell 1863 Electrograph 1755, 1623 ESA 0812 Fujitsu 0809, 0683, 0853, 2008 Funai 1271 Gateway 1755, 1001, 1002, 1003, 1756 Haier 1748 Harsper 1206 Norwood Micro 1286, 1296 NuVision 1657, 2158 Olevia 1610, 1144, 1240, 1331 Panasonic 1480, 0650, 1941 PARK 2194, 2202 Petters 1523 Philips 1454, 1483, 1744, 1867 Pioneer 1260 RCA 1447 Samsung 0812, 0702 Sharp 0688, 0689 Toshiba 1256