

Code Lists / Liste des codes / Lista de Códigos

Audio

Amplifier / Amplificateur / Amplificador	
Durabrand	1561
Harman/Kardon	0892
JVC	0331
Left Coast	0892
Lennox	1561
Marantz	0892
Optimus	1189
Philips	0892
Pioneer	1390
Polk Audio	0892
RCA	0823
Sony	0815
Victor	0331
Yamaha	0354

Receiver / Récepteur / Receptor	
Accurian	2098
Aiwa	1405, 0189, 0121, 1243, 1641
Akai	1512
Alco	1390
Anam	1609, 1074
Apex Digital	1257, 1430, 1774
Audiotronic	1189
Audiovox	1390
B & K	0701, 0820, 0840
Bose	1229, 0639, 1253, 1629, 1841, 1933
Cambridge Soundworks	1370, 2297
Carver	1189, 0189
Daewoo	1250
Denon	1360, 1142, 2279, 2857
Fisher	1801
Gateway	1517
Go Video	1532
Harman/Kardon	0189, 0891, 1304, 1306, 2241
Hitachi	1801
Insignia	1030, 1077, 1893, 2169, 2175
Integra	0135, 1298, 1320, 1805
JBL	1374, 1676, 1871, 2239, 2331
Kenwood	1313, 1570, 1569, 0186
KLH	1390, 1412, 1428
Koss	1366
LG	1293, 2197
Linn	0189
Magnavox	1189, 1269, 0189, 0391, 1514
Marantz	1189, 1269, 0189, 1289
Mitsubishi	1393
Onkyo	0135, 0842, 1298, 1320, 1531, 1805
Optimus	1023, 0186, 1074
Oritron	1366
Panasonic	1308, 0367, 1288, 1316, 1548, 1633, 1763, 1764, 2967
Philips	1189, 1269, 0189, 0391, 1266, 1831, 2311
Pioneer	1023, 0244, 0630, 1123, 1384, 1935
Polaroid	1508
Polk Audio	0189, 1289
Proscan	1254
RCA	1023, 1609, 1254, 1074, 1123, 1390, 1511, 2041
Rio	1869

Cable / Câble	
Amino	1602, 1822
Bright House	1376, 1877
Cable One	1376, 1877
Cablevision	1376, 1877
Charter	1376, 1877, 2187
Cisco	1877, 0877, 1982
Comcast	1376, 1877, 1982, 2576
Cox	1376, 1877
Digeo	1187, 2187
Director	0476
LG	1293, 2197
Linn	0189
Magnavox	1189, 1269, 0189, 0391, 1514
Marantz	1189, 1269, 0189, 1289
Mitsubishi	1393
Onkyo	0135, 0842, 1298, 1320, 1531, 1805
Optimus	1023, 0186, 1074
Oritron	1366
Panasonic	1308, 0367, 1288, 1316, 1548, 1633, 1763, 1764, 2967
Philips	1189, 1269, 0189, 0391, 1266, 1831, 2311
Pioneer	1023, 0244, 0630, 1123, 1384, 1935
Polaroid	1508
Polk Audio	0189, 1289
Proscan	1254
RCA	1023, 1609, 1254, 1074, 1123, 1390, 1511, 2041
Rio	1869

Satellite / Satélite	
Bell ExpressVu	0775, 1170
Chaparral	0216
Coolsat	1806
Voom	0869
Crossdigital	1109
DirectTV	1377, 0392, 0566, 0639, 1639, 1142, 0247, 0749, 1749, 1856, 1076, 1109, 1189, 1414, 1442, 1443, 1609, 1708
Dish Network System	0775, 1505, 1170, 1775
Dishpro	0775, 1505, 1775
Echostar	0775, 1505, 1170, 1775
Expressvu	0775, 1775
GE	0566
General Instrument	0869
GOI	0775, 1775
Hitachi	1250
HTS	0775, 1775
Hughes Network Systems	1142, 0749, 1749, 1442, 1443
Humax	1790
JVC	0775, 1170, 1775
LG	1414
Mitsubishi	0749
Motorola	0869
Next Level	0869
Panasonic	0247, 0701, 1189
Pansat	1807
Philips	1142, 0749, 1749, 1076, 1442
Proscan	0392, 0566
RadioShack	0869
RCA	0566, 0143
Samsung	1377, 1276, 1109, 1442, 1609, 1708
Sony	0639, 1639
Star Choice	0869
Tivo	1142, 1442, 1443

Audio Accessories / Accessoires de audio / Accesorios de audio	
Accurian	1106
Altec Lansing	0607
Apple	1115, 1644
D-Link	1522
DLO	1155
GPX	2113
Griffin	1891
iDeck	1106
iLive	2113
Monitor Audio	1106
NaviPod	1644
Netgear	1785
Roku	1828
SSI	1522
Yamaha	1809, 1810

Cable-DVR Combos / Combinés Câble - DVR / Combos de Cable-DVR	
Amino	1822
Bright House	1376, 1877
Cable One	1376, 1877
Cablevision	1376, 1877
Charter	1376, 1877, 2187
Cisco	1877, 0877, 1982
Comcast	1376, 1877, 1982, 2576
Cox	1376, 1877
Digeo	1187, 2187
Director	0476
LG	1293, 2197
Linn	0189
Magnavox	1189, 1269, 0189, 0391, 1514
Marantz	1189, 1269, 0189, 1289
Mitsubishi	1393
Onkyo	0135, 0842, 1298, 1320, 1531, 1805
Optimus	1023, 0186, 1074
Oritron	1366
Panasonic	1308, 0367, 1288, 1316, 1548, 1633, 1763, 1764, 2967
Philips	1189, 1269, 0189, 0391, 1266, 1831, 2311
Pioneer	1023, 0244, 0630, 1123, 1384, 1935
Polaroid	1508
Polk Audio	0189, 1289
Proscan	1254
RCA	1023, 1609, 1254, 1074, 1123, 1390, 1511, 2041
Rio	1869

Satellite-DVR Combos / Combinés Satellite - DVR / Combos de Satélite-DVR	
Bell ExpressVu	0775, 1170
DirectTV	1377, 0392, 0639, 1142, 1076, 1442, 1443
Dish Network System	0775, 1505
Dishpro	0775, 1505
Echostar	0775, 1505, 1170
Expressvu	0775, 1505
GE	0566
General Instrument	0869
GOI	0775, 1775
Hitachi	1250
HTS	0775, 1775
Hughes Network Systems	1142, 0749, 1749, 1442, 1443
Humax	1790
JVC	0775, 1170, 1775
LG	1414
Mitsubishi	0749
Motorola	0869
Next Level	0869
Panasonic	0247, 0701, 1189
Pansat	1807
Philips	1142, 0749, 1749, 1076, 1442
Proscan	0392, 0566
RadioShack	0869
RCA	0566, 0143
Samsung	1377, 1276, 1109, 1442, 1609, 1708
Sony	0639, 1639
Star Choice	0869
Tivo	1142, 1442, 1443

DVD / Lecteurs DVD	
Accurian	0675, 1416
Advent	1016
Aiwa	0641
Akai	0695, 0770, 0899, 1089
Alco	0790
Allegro	0869
Amphion Media Works	0872, 1245
AMW	0872, 1245
Apex Digital	0672, 0717, 0755, 0794, 0796, 0797, 0830, 1004, 1056, 1061, 1100, 1480
Arrgo	1023
Aspire Digital	1168, 1407
Charter	1489, 1678
Audiovox	0790, 1121, 1122
B & K	0662
BBK	1224
Bel Canto Design	1571
Blaupunkt	0717
Blue Parade	0571
Loewe	0511
Magnavox	0503, 0539, 0646, 0675, 0821, 1268, 1354, 1472, 1506
Malata	0782
Marantz	0539, 2414
McIntosh	1273
Memorex	0695, 0831, 1270, 2213
Microsoft	0522, 2083
Mintek	0839, 0717, 1472
Mitsubishi	1521, 0521
NAD	0831
Coby	0778, 0852, 1086, 1107, 1165, 1177, 1351
Scientific Atlanta	0831
Suddenlink	1376, 1877
Time Warner	1376, 1877, 2187
Tivo	2576

Satellite-DVR Combos / Combinés Satellite - DVR / Combos de Satélite-DVR	
Bell ExpressVu	0775, 1170
DirectTV	1377, 0392, 0639, 1142, 1076, 1442, 1443
Dish Network System	0775, 1505
Dishpro	0775, 1505
Echostar	0775, 1505, 1170
Expressvu	0775, 1505
GE	0566
General Instrument	0869
GOI	0775, 1775
Hitachi	1250
HTS	0775, 1775
Hughes Network Systems	1142, 0749, 1749, 1442, 1443
Humax	1790
JVC	0775, 1170, 1775
LG	1414
Mitsubishi	0749
Motorola	0869
Next Level	0869
Panasonic	0247, 0701, 1189
Pansat	1807
Philips	1142, 0749, 1749, 1076, 1442
Proscan	0392, 0566
RadioShack	0869
RCA	0566, 0143
Samsung	1377, 1276, 1109, 1442, 1609, 1708
Sony	0639, 1639
Star Choice	0869
Tivo	1142, 1442, 1443

DVD / Lecteurs DVD	
Accurian	0675, 1416
Advent	1016
Aiwa	0641
Akai	0695, 0770, 0899, 1089
Alco	0790
Allegro	0869
Amphion Media Works	0872, 1245
AMW	0872, 1245
Apex Digital	0672, 0717, 0755, 0794, 0796, 0797, 0830, 1004, 1056, 1061, 1100, 1480
Arrgo	1023
Aspire Digital	1168, 1407
Charter	1489, 1678
Audiovox	0790, 1121, 1122
B & K	0662
BBK	1224
Bel Canto Design	1571
Blaupunkt	0717
Blue Parade	0571
Loewe	0511
Magnavox	0503, 0539, 0646, 0675, 0821, 1268, 1354, 1472, 1506
Malata	0782
Marantz	0539, 2414
McIntosh	1273
Memorex	0695, 0831, 1270, 2213
Microsoft	0522, 2083
Mintek	0839, 0717, 1472
Mitsubishi	1521, 0521
NAD	0831
Coby	0778, 0852, 1086, 1107, 1165, 1177, 1351
Scientific Atlanta	0831
Suddenlink	1376, 1877
Time Warner	1376, 1877, 2187
Tivo	2576

Satellite-DVR Combos / Combinés Satellite - DVR / Combos de Satélite-DVR	
Bell ExpressVu	0775, 1170
DirectTV	1377, 0392, 0639, 1142, 1076, 1442, 1443
Dish Network System	0775, 1505
Dishpro	0775, 1505
Echostar	0775, 1505, 1170
Expressvu	0775, 1505
GE	0566
General Instrument	0869
GOI	0775, 1775
Hitachi	1250
HTS	0775, 1775
Hughes Network Systems	1142, 0749, 1749, 1442, 1443
Humax	1790
JVC	0775, 1170, 1775
LG	1414
Mitsubishi	0749
Motorola	0869
Next Level	0869
Panasonic	0247, 0701, 1189
Pansat	1807
Philips	1142, 0749, 1749, 1076, 1442
Proscan	0392, 0566
RadioShack	0869
RCA	0566, 0143
Samsung	1377, 1276, 1109, 1442, 1609, 1708
Sony	0639, 1639
Star Choice	0869
Tivo	1142, 1442, 1443

DVD / Lecteurs DVD	
Accurian	0675, 1416
Advent	1016
Aiwa	0641
Akai	0695, 0770, 0899, 1089
Alco	0790
Allegro	0869
Amphion Media Works	0872, 1245
AMW	0872, 1245
Apex Digital	0672, 0717, 0755, 0794, 0796, 0797, 0830, 1004, 1056, 1061, 1100, 1480
Arrgo	1023
Aspire Digital	1168, 1407
Charter	1489, 1678
Audiovox	0790, 1121, 1122
B & K	0662
BBK	1224
Bel Canto Design	1571
Blaupunkt	0717
Blue Parade	0571
Loewe	0511
Magnavox	0503, 0539, 0646, 0675, 0821, 1268, 1354, 1472, 1506
Malata	0782
Marantz	0539, 2414
McIntosh	1273
Memorex	0695, 0831, 1270, 2213
Microsoft	0522, 2083
Mintek	0839, 0717, 1472
Mitsubishi	1521, 0521
NAD	0831
Coby	0778, 0852, 1086, 1107, 1165, 1177, 1351
Scientific Atlanta	0831
Suddenlink	1376, 1877
Time Warner	1376, 1877, 2187
Tivo	2576

Satellite-DVR Combos / Combinés Satellite - DVR / Combos de Satélite-DVR	
Bell ExpressVu	0775, 1170
DirectTV	1377, 0392, 0639, 1142, 1076, 1442, 1443
Dish Network System	0775, 1505
Dishpro	0775, 1505
Echostar	0775, 1505, 1170
Expressvu	0775, 1505
GE	0566
General Instrument	0869
GOI	0775, 1775
Hitachi	1250
HTS	0775, 1775
Hughes Network Systems	1142, 0749, 1749, 1442, 1443
Humax	1790
JVC	0775, 1170, 1775
LG	1414
Mitsubishi	0749
Motorola	0869
Next Level	0869
Panasonic	0247, 0701, 1189
Pansat	1807
Philips	1142, 0749, 1749, 1076, 1442
Proscan	0392, 0566
RadioShack	0869
RCA	0566, 0143
Samsung	1377, 1276, 1109, 1442, 1609, 1708
Sony	0639, 1639
Star Choice	0869
Tivo	1142, 1442, 1443

DVD / Lecteurs DVD	
Accurian	0675, 1416
Advent	1016
Aiwa	0641
Akai	0695, 0770, 0899, 1089
Alco	0790</

TV/VCR Combos / Combinés téléviseur -magnétoscope / Combos de TV-VCR

Controlled by TV / Contrôlé par TV / Controlado por TV	
America Action.....	0180
Audiovox.....	0180
Emerson.....	0236
Controlled by VCR / Contrôlé par VCR / Controlado por VCR	
Broksonic.....	0002, 1479
Citizen.....	1278
Colt.....	0072
Curtis Mathes.....	1035
Daewoo.....	1278
Emerson.....	0002, 0593, 1278, 1479
Funai.....	0000
GE.....	0240, 0807, 1035, 1060
GoldStar.....	1237
Harley Davidson.....	0000
Hitachi.....	0000
LG.....	1037
Lloyd's.....	0000
Magnasonic.....	0593, 1278
Magnavox.....	0000, 0593, 1781
Magnin.....	0240
Memorex.....	0162, 1037, 1162, 1237, 1262
MGA.....	0240
Mitsubishi.....	0807
Optimus.....	0162, 0593, 1162, 1262
Orion.....	0002, 1479
Panasonic.....	0162, 1035, 1162, 1262
Penney.....	0240, 1035, 1237
Quasar.....	0162, 1035, 1162
RadioShack.....	0000, 1037
RCA.....	0240, 0807, 1035, 1060
Samsung.....	1014
Sansui.....	0000, 1479
Sanyo.....	0240
Sears.....	0000, 1237
Sony.....	1232, 0000
Sylvania.....	1781
Symphonic.....	0000, 0593
Thomas.....	0000
Toshiba.....	0845, 1145
Zenith.....	0000, 1479

DVRS

ABS.....	1972
Alienware.....	1972
Bell ExpressVu.....	1944
CyberPower.....	1972
Dell.....	1272
DirecTV.....	0739, 0740
Dish Network System.....	1944
Dishpro.....	1944
Echostar.....	1944
ExpressVu.....	1944
Gateway.....	1972
Go Video.....	0614
GOL.....	1944
Emerson.....	0002, 0593, 1278, 1479
Hewlett Packard.....	1972
Howard Computers.....	1972
GE.....	0240, 0807, 1035, 1060
GoldStar.....	1237
Harley Davidson.....	0000
Hitachi.....	0000
LG.....	1037
Lloyd's.....	0000
Magnasonic.....	0593, 1278
Magnavox.....	0000, 0593, 1781
Magnin.....	0240
Memorex.....	0162, 1037, 1162, 1237, 1262
MGA.....	0240
Mitsubishi.....	0807
Optimus.....	0162, 0593, 1162, 1262
Orion.....	0002, 1479
Panasonic.....	0162, 1035, 1162, 1262
Penney.....	0240, 1035, 1237
Quasar.....	0162, 1035, 1162
RadioShack.....	0000, 1037
RCA.....	0240, 0807, 1035, 1060
Samsung.....	1014
Sansui.....	0000, 1479
Sanyo.....	0240
Sears.....	0000, 1237
Sony.....	1232, 0000
Sylvania.....	1781
Symphonic.....	0000, 0593
Thomas.....	0000
Toshiba.....	0845, 1145
Zenith.....	0000, 1479

DTV Converters / Récepteurs TV numériques / Convertidores Digitales

Access HD.....	2185
Airlink 101.....	2491
Alpha Digital.....	2185
AMTC.....	1563
Apex Digital.....	2478
Artec.....	2490
CASTI.....	2305
Channel Master.....	2365
Coship.....	2487
Daewoo.....	2338
Daytek.....	2305
Digital Stream.....	2303
Dish Network System.....	2470
Echostar.....	2470
Evolution.....	2479
GE.....	2360, 2450
Goodmind.....	2488

TVs / Téléviseurs

Accurian.....	1803
Action.....	0873
Admiral.....	0093, 0463
Aiiko.....	0761, 0783, 0815, 0817, 0842, 1933
Akai.....	0809, 0683, 0853, 2008
Albatron.....	0180, 0171, 1271, 1963
America Action.....	0180
Ampro.....	0751
Anam.....	0180
AOC.....	0030, 1365, 1590, 2014
Aomni.....	1623
Apex Digital.....	0748, 0879, 0765, 0767, 0890, 1217, 1943, 1991
Astar.....	1272
Audiovox.....	0451, 0180, 0092, 0623, 0710, 0802, 0846, 0875, 1284, 1937, 1951, 1952
Insignia.....	1348, 1351, 1352
Aventura.....	0171
Axon.....	1206
Bell & Howell.....	1415
Linksys.....	1272
Magnavox.....	1563
Media Center PC.....	1272
Memorex.....	2486
MicroGEM.....	1283
Microsoft.....	1272
Mind.....	1272
Motorola.....	1998, 0858, 2378
Niveus Media.....	1272
Celebrity.....	0000
Celera.....	0765
Changhong.....	0765
Cinego.....	1986
Ricavision.....	0060, 0030, 0092, 0017
Roku.....	2371
Sansonic.....	2348
Coby.....	2017
Commercial Solutions.....	1447, 0047
Sony.....	1272, 1324
Stack 9.....	1272
SureWest.....	1481
Sylvania.....	1563
Systemax.....	1272
Tagar Systems.....	0145, 0166, 0466, 1147, 1347
Tivax.....	2185
Crown.....	0054
Sylvania.....	0180
Curtis Mathes.....	0047, 0054, 0154, 0451, 0093, 0060, 0702, 0030, 0145, 0166, 0466, 1147, 1347
Systemax.....	0180
Tagar Systems.....	0145, 0166, 0466, 1147, 1347
Tivax.....	2185
Toshiba.....	1272
Zenith.....	1415
Zentech.....	2491
Zinwell.....	2488

TVs / Téléviseurs

Ventura.....	2454
Venturer.....	2454
Verizon.....	2254, 2586
Viewsonic.....	1272
Voodoo.....	1272
Vudu.....	2298
Durabrand.....	0463, 0180, 0178, 0171, 1034
Winegard.....	2454
Zenith.....	1415
Apex Digital.....	2478
Artec.....	2490
AT&T.....	0858
CASTI.....	2305
Channel Master.....	2365
Cisco.....	2345
Coship.....	2487
CyberPower.....	1272
Daewoo.....	2338
Daytek.....	2305
Digital Stream.....	2303
Dish Network System.....	2470
Echostar.....	2470
Entone.....	2302
Advent.....	1563
Evolution.....	2479
Gateway.....	1272
Mind.....	2360, 2450
Goodmind.....	2450
Gridlink.....	2348
Hewlett Packard.....	1272
Howard Computers.....	1272
RCA.....	0030, 1365, 1590, 2014
Aomni.....	1623
Apex Digital.....	0748, 0879, 0765, 0767, 0890, 1217, 1943, 1991
Astar.....	1272
Audiovox.....	0451, 0180, 0092, 0623, 0710, 0802, 0846, 0875, 1284, 1937, 1951, 1952
Insignia.....	1348, 1351, 1352
Aventura.....	0171
Axon.....	1206
Bell & Howell.....	1415
Linksys.....	1272
Magnavox.....	1563
Media Center PC.....	1272
Memorex.....	2486
MicroGEM.....	1283
Microsoft.....	1272
Mind.....	1272
Motorola.....	1998, 0858, 2378
Niveus Media.....	1272
Celebrity.....	0000
Celera.....	0765
Changhong.....	0765
Cinego.....	1986
Ricavision.....	0060, 0030, 0092, 0017
Roku.....	2371
Sansonic.....	2348
Coby.....	2017
Commercial Solutions.....	1447, 0047
Sony.....	1272, 1324
Stack 9.....	1272
SureWest.....	1481
Sylvania.....	1563
Systemax.....	1272
Tagar Systems.....	0145, 0166, 0466, 1147, 1347
Tivax.....	2185
Toshiba.....	1272
Zenith.....	1415
Zentech.....	2491
Zinwell.....	2488

TVs / Téléviseurs

Daewoo.....	0451, 0092, 1661, 0623, 0661, 0672
Dell.....	1264, 1080, 1178, 1403, 1863
Denon.....	0145
Diamond Vision.....	1996, 1997
Digital Lifestyles.....	1765
Marantz.....	0054, 0030, 0704, 0854, 0855, 1154, 1398
Matsushita.....	0250, 0650
Maxent.....	1755, 0762, 1211, 1757
Megapower.....	0700
Megatron.....	0178, 0145
Memorex.....	0154, 0463, 0150, 0178
MGA.....	0150, 0178, 0030
Midland.....	0047, 0017, 0051
Mintek.....	1603, 1990
Mitsubishi.....	1250, 0093, 0150, 0178, 0836, 0868, 1550
Monivision.....	0700, 0843
Motorola.....	0093, 0835
Moxell.....	0835
MTC.....	0060, 0030
Multitech.....	0180
NAD.....	0156, 0178, 0866, 1156
NEC.....	0030, 0497, 0882, 1398, 1704
NetTV.....	1755, 0762
Nexus Electronics.....	2183
Nikko.....	0178, 0030, 0092
Norcent.....	0748, 0824, 1089, 1365, 1589, 1590, 1591
Norwood Micro.....	1286, 1296, 1303
NTC.....	0093, 0864
NuVision.....	1657, 2158
Olevia.....	1610, 1144, 1240, 1331
Olympus.....	1342
Onwa.....	0180
Optimus.....	0250, 0154, 0166, 0650
Optoma.....	0887
Optonica.....	0890
Orion.....	0236, 0463, 1463
Panasonic.....	0250, 1480, 0051, 0650, 1291, 1941, 1946, 1947
PARK.....	2194, 2202
Penney.....	0047, 0156, 0051, 0060, 0178, 0030, 1347
Petters.....	1523
Philco.....	0054, 0030
Philips.....	1454, 0054, 0690, 1154, 1483, 1744, 1867
Pioneer.....	1457, 0166, 0679, 0866, 1260, 1398
Planar.....	0463
Polaroid.....	1523, 0765, 2121, 2120, 2119, 2002, 1992, 1991, 1962, 1769, 1767, 1766, 1687, 1498, 1341, 1328, 1327, 1326, 1316, 1314, 1286, 1276, 1262, 0865
iLo.....	1286, 1603, 1665, 1684, 1990
Infinity.....	0054
Initial.....	1603, 1990
Princeton.....	0700
Prism.....	0017
Proscan.....	1447, 0047, 1347, 2147, 2256
Proton.....	0178, 0466
Protron.....	1320, 1323
Proview.....	0835, 1498, 1687
Pulsar.....	0017
Puneeet.....	1546
Crosley.....	0054
Kenwood.....	0180
KLH.....	0765, 0767, 1962
Kost.....	1262, 1483
KTV.....	1953, 1958, 2002, 2187, 2247
Realistic.....	0154, 0180, 0178, 0030
RevolutionHD.....	1623

TVs / Téléviseurs

Runco.....	0017, 0030, 0497, 0603, 1398, 1629
Sampo.....	1755, 0030, 0762
Samsung.....	0812, 0060, 0702, 0178, 0030, 0766, 0814, 1060, 1575, 1903
Sansui.....	0463, 1409, 1935
Sanyo.....	0154, 0088, 0799, 0893, 1142
Sceptre.....	0878, 1217, 1360, 1599
Scotch.....	0178
Scott.....	0236, 0180, 0178, 1711
Samsung.....	0047, 0054, 0154, 0156, 0178, 0171
Sharp.....	0818, 0093, 0491, 0688, 0689, 0851, 1602
Sheng Chia.....	0093
Sherwood.....	1524, 1306
Signet.....	1262
SIM2 Multimedia.....	0812, 1060
Sharp.....	1297
SVL.....	0872
Toshiba.....	1524, 1306
Vizio.....	1499